

工业二维条码扫描器

Concise general manual

DT.IN.000009

装箱单

产品中物品如下图所示：

物品名称	数量
扫描器	1
数据线	1
说明书	1
保修卡	1

产品适用范围

本产品适用在轻度粉尘环境下操作，不可淋雨。

本产品不适宜在需要日常碰撞的工厂流水线等

环境下适用，如需要更高性能的条码扫描器，

请向您的供应商获取更详细的产品列表。

-1-

产品对下列条码具有良好的识读性

零售商品条码

快递物流条码

服装吊牌条码

药品条码

烟酒条码

及绝大多数印刷条码

条码扫描的技巧

- 光线完全覆盖条码
- 调整扫描器与条码的距离将光束对准条码，按动开关按钮，使瞄准光束位于条码的正中。如果条码较小，应使扫描器靠近条码；如果条码较大，应使扫描器离条码远一点，这样更容易读取条码。您可能需要以某一角度倾斜扫描器。
- 扫二维码时，若扫描枪距离二维码太近读取不成功时，应将距离调整拉大。



-2-

日常维护

- 如果扫描器的窗口不干净，扫描器的性能会下降，当窗口占有灰尘或油污时，请用无尘布或沾少许水的擦镜布擦拭干净，勿用酒精或化学品擦拭。
- 经常检查条码扫描器的连接端和连接线。条码扫描器的连接端或连接线是日常损耗品，当发现其损坏时，请及时更换。
- 我们一开始就为每个产品制定了相应的可靠性保护，几乎不需要特别额外的日常维护，但条码扫描器是有精密电子器件组成，为避免不必要的损失，我们依然建议您轻拿轻放，勿强力拉拽线缆，勿摔打和雨淋，避免粉尘环境，以延长产品使用寿命。

条码扫描器的基本设置



恢复出厂设置



读取版本信息

-3-

接口设置



USB键盘模式



USB虚拟串口模式

声音设置



上电声音打开



读码成功声音开启

反白条码设置



开启反白条码设置



关闭反白条码设置

扫描模式设置



手动模式



连续模式

-4-



感应模式



闪烁模式

后缀设置



后缀加回车



后缀加TAB



后缀回车换行



取消后缀

USB传输速度



快 1MS



中 5MS



慢 10MS

-5-

Industrial 2D barcode scanner

Concise general manual

DT.IN.000009

Packing List

The following items included :

Items	Quantity
sacnner	1
Data Cable	1
General Manual	1
Warranty Card	1

Scope of application

The product is applicable to operation in mild dusten vironment and must not get wet in the rain.The product is not applicable to environment under which daily collision and drop is inevitable, such as the factory assembly line. If you need a barcode scanner with higher performance, please get a more detailed product list from your supplier.

-1-

Barcode scanning technique

- Make the laser line fully cover the barcode.
- Adjust the distance between scanner and barcode to make the laser line aim at the barcode, then press the button to make the aiming beam right in the middle of the barcode. If the barcode is small, make the scanner closer to the barcode, and if the barcode is large, make the scanner farther from the barcode. In this way, it is easier to read the barcode. You may need to tilt the scanner at a certain angle.



-2-

Daily maintenance

- If the scanner window is not clean, the scanner's performance will be reduced. When the window is dusty or greasy, wipe it with a clean cloth or a little water-picking cloth. Do not wipe it with alcohol or chemicals.
- Always check the connector of the barcode scanner and the cable. The barcode scanner connector or connection line is a daily consumer goods. When it is found damaged, please replace it in time.
- We initially set up the corresponding reliability protection for each product. Almost no special extra routine maintenance is needed. However, the barcode scanner consists of sophisticated electronic components. To avoid unnecessary losses, we still recommend that you take and put it lightly. Do not drag the cable rudely. Do not smash it and get it wet in the rain. And avoid dust environment to extend the service life of the product.

Basic settings for barcode scanner



Restore factory defaults



Reading version information

-3-

Interface settings



USB keyboard mode



USB virtual COM port

Voice settings



Voice open after power on



Voice open after reading successfully

Voice close after reading successfully

Anti-white code settings



open anti-white code



Close anti-white code

Scanning mode settings



Trigger mode



Continuous mode

-4-



Sensing mode



Flash mode

Suffix settings



Add suffix Enter



Add suffix TAB



Add suffix CRLF



Cancel suffix

USB transfer speed



Fast 1MS



Medium 5MS



Slow 10MS

-5-